



SmartCOMM™ Hosted IP Complete

Yealink T42S IP Phone Reference Guide



Lines
Use these keys to activate up to sixteen accounts and assign various features.

Power Indicator

Soft Keys
Label automatically to identify their context-sensitive features.

Mute Key
Mutes the call so that your caller cannot hear you.

Headset Key
Activates hands free for making and receiving calls without lifting the handset.

Message Key
Accesses voice messages.

Redial Key
Redials a previously dialed number.

Speakerphone Key
Activates hands free for making and receiving calls without lifting the handset.

Navigation Keys
Use the arrows to navigate through the selections on the screen. Press the center circle to select.

Volume Keys
Adjusts the volume of the handset, headset, speakerphone and ringer.

SmartCOMM™ Hosted IP Complete

Yealink T42S IP Phone Reference Guide



Basic Phone Features

MAKE A CALL

1. Dial the call.
2. Lift the handset or press the Speakerphone or Headset keys.

ANSWERING A CALL











For hands free operation, press the Speakerphone key.













REDIAL

Press the Redial Key to call the previously dialed number.

ENDING CALLS

Replace the handset or press the End Call soft key.

Symbol	Key Description
	NETWORK IS UNAVAILABLE
	REGISTERED SUCCESSFULLY
	REGISTER FAILED
	REGISTERING
	HANDS-FREE SPEAKERPHONE MODE
	HANDSET MODE
	HEADSET MODE
	VOICEMAIL
	AUTO ANSWER
	CALL HOLD

Symbol	Key Description
	CALL MUTE
	RINGER VOLUME IS ZERO (0)
	DO NOT DISTURB
	PHONE LOCK
	MISSED CALLS
	RECEIVED CALLS
	PLACED CALLS
	MUTE KEY – Mutes the call so that your caller cannot hear you.
	HEADSET KEY – Activates hands free for making and receiving calls without lifting the handset.
	MESSAGES KEY – Press to retrieve voicemails.
	REDIAL KEY – Redials a previously dialed number.
	SPEAKERPHONE KEY – Activates hands free for making and receiving calls without lifting the handset.